



M-Power



M-Power is Here!

Made to meet the demands of the Contract Market, M-Power is an exceptional choice for Healthcare, Hospitality, and Corporate seating.

M-Power is equipped with:

- Excellent stain resistance with enhanced abrasion and cleanability
- Anti-microbial, anti-bacterial, and hydrolytic stability: 5-week Hydrolysis
- Features a simple geometric emboss in 24 fun, vibrant colors, including a wide range of neutral colors

Specifications

- Roll Width: 54 inches
- Roll Size: 30 yards
- Weight: 13.3 ± 0.7 oz per linear yard
- Thickness: 41 ± 5 mils
- Anti-Bacterial / Anti-Microbial
- Stain Resistant Finish
- Hydrolytic Stability: 5-week Hydrolysis

- Abrasion Resistance: No significant wear after 200,000 double rubs with #8 cotton duck using the Wyzenbeek test method.

Flame Resistance

Manufactured to meet the following flammability* requirements:

- California Flammability Regulation (Bulletin 117, Section E)
- BIFMA Class 1 / NFPA 260A
- FMVSS 302
- UFAC Class 1

* This term and corresponding data refer to typical performance in the specific test indicated and should not be construed to imply the behavior of this or any other material under actual fire conditions.

Care and Cleaning Instructions

In general, most common stains can be cleaned using warm, soapy water and clear water rinses. Moderate scrubbing with a medium bristle brush will help loosen soiling materials from the depressions of embossed surfaces. For more stubborn stains, use Formula 409® commercially available cleaner† in accordance with the manufacturer's instructions.

Full strength rubbing alcohol or mineral spirits†† may be tried cautiously as a last resort on very stubborn stains, if the above suggestions do not work. Indiscriminate use of any solvent, or solvent containing cleaner, can severely damage or discolor PU. Always follow with a clear water rinse after cleaning with solvents.

Note: Detergents should never be used on a regular or repeated basis for normal cleaning. Morbern recommends repeated rinsing with clear water after any cleaning procedure.

† When opening a new container, please test the cleaner in an inconspicuous area as cleaning manufacturers may change formula without notice.

Morbern cannot be responsible when unknown changes are made by the manufacturer of the cleaner to their formulations between our 6-month verification intervals.

†† Caution: Exercise care as these solvents are flammable. Use only small quantities of solvents and keep clear of any sources of ignition. Wear protective gloves and ensure cleaning takes place in a well ventilated area.

Morbern is an ISO 9001:2008 Certified Producer

©2015 Morbern, Inc.

Recommended Applications

- Conference Room Seating
- Home Office Seating
- Executive Seating
- Hotel/Motel Seating
- Foyer and Lounge Seating
- Residential Seating
- General Office Seating
- Work Station Seating
- Healthcare Seating

Care and Cleaning Guide

Stain	Cleaning Procedure‡
Red Wine	4 ∞
Coffee / Soda	4
Ball Point Pen / Permanent Marker	3 to 4
Ketchup / Mustard	4
Lipstick / Sun Block	4
Machine Oil / Grease	4
Soy Sauce / BBQ Sauce	4

‡ The rating for stain resistance is based on the following scale:

- Removed after 8 hours and cleaned with water and Formula 409®
- Removed after 8 hours and cleaned with water, Formula 409® and alcohol (70%)

Rating System ∞

Stain	Cleaning Procedure‡
No staining marks on surface	4
Slight stain on surface	3
Strong stain on surface	2
No cleanability at all	1

www.morbern.com



To order or to receive samples and more information on Mulberry, please call us at 888-MORBERN or email us at sales@morbern.com. visit us 24 hours, 7 days a week at www.morbern.com for product information, samples, and more.

