



Mulberry



Introducing Mulberry

Made to meet the demands of the Contract Market, Mulberry is a remarkable choice for Hospitality, Healthcare, and Corporate seating.

Mulberry is equipped with:

- Resistance to most of the common chemicals used for sterilization and cleaning in medical environments
- Bacterial Resistance to Staphylococcus Aureus Klebsiella Pneumoniae
- Features MorCare™ branded protection and a retro inspired, sophisticated pattern and eight colors, it is sure to perform in any environment

Specifications

- Roll Width: 54 inches
- Roll Size: 30 yards
- Weight: 32.25 ± 1.5 oz per linear yard
- Thickness: 38 ± 4 mils
- Mildew + Bacteria (Staph) Resistant
- Anti-Static Slip Finish
- Urine Stain Resistant
- Sulfide Stain Resistant
- Enhanced Bleach Resistance
- Abrasion Resistance: No significant wear after 200,000 double rubs with #8 cotton duck using the Wyzenbeek test method.
- Oil Resistant
- Cold Crack: -25°F

Flame Resistance

Manufactured to meet the following flammability* requirements:

- California Flammability Regulation (Bulletin 117, Section E)
- FAA, FAR 25.853(a) + Appendix F Part 1 (a)(I)(ii)
- Fed Std 191-A-5903.1 (CID-A-A2950A) formerly CCC A-680a
- FMVSS 302
- UFAC Class 1
- CID A A-2950A
- Port Authority of NY and NJ
- BIFMA Class 1 / NFPA 260A

* This term and corresponding data refer to typical performance in the specific test indicated and should not be construed to imply the behavior of this or any other material under actual fire conditions.

Care and Cleaning Instructions

In general, most common stains can be cleaned using warm, soapy water and clear water rinses. Moderate scrubbing with a medium bristle brush will help loosen soiling materials from the depressions of embossed surfaces. For more stubborn stains, use Formula 409® commercially available cleaner† in accordance with the manufacturer's instructions.

Full strength rubbing alcohol or mineral spirits†† may be tried cautiously as a last resort on very stubborn stains, if the above suggestions do not work. Indiscriminate use of any solvent, or solvent containing cleaner, can severely damage or discolor PU. Always follow with a clear water rinse after cleaning with solvents.

Note: Detergents should never be used on a regular or repeated basis for normal cleaning. Morbern recommends repeated rinsing with clear water after any cleaning procedure.

† When opening a new container, please test the cleaner in an inconspicuous area as cleaning manufacturers may change formula without notice.

Morbern cannot be responsible when unknown changes are made by the manufacturer of the cleaner to their formulations between our 6-month verification intervals.

†† Caution: Exercise care as these solvents are flammable. Use only small quantities of solvents and keep clear of any sources of ignition. Wear protective gloves and ensure cleaning takes place in a well ventilated area.

Morbern is an ISO 9001:2008 Certified Producer

©2015 Morbern, Inc.

Disinfecting

Bleach Cleanable

When disinfecting with bleach, dilute with water up to 9:1 ratio (10%) / Liberally apply diluted disinfectant using a sponge. Rinse with cold water several times. Wipe dry and repeat if necessary. Federal regulations require that guidelines on the bleach label need to be followed for antiseptic or antimicrobial purposes.

The following disinfecting cleaners, when used in accordance with the manufacturer's cleaning instructions and followed by a clear water rinse, are approved for use on MorCare™ vinyls:

- Asepticare TB II
- Lysol Foaming
- Birex
- Precise (Caltech)
- Cavicide (Metyrex)
- Super Sani-Cloth PDI
- Citrace (Caltech)
- Virex 256
- Dispatch
- Wex-cide
- Virox 5 Johnson Diversy Canada
- CaviWipes

Recommended Applications

- Healthcare Seating
- Hospitality Seating
- Conference Room Seating
- Home Office Seating
- Executive Seating
- Hotel/Motel Seating
- Foyer and Lounge Seating
- Residential Seating
- General Office Seating
- Work Station Seating


Contents:

Face: 100% Virgin Vinyl

Back: 100% Polyester

www.morbern.com



 To order or to receive samples and more information on Mulberry, please call us at 888-MORBERN or email us at sales@morbern.com. visit us 24 hours, 7 days a week at www.morbern.com for product information, samples, and more.

